

WELCOME

Congratulations on becoming a Yoder Smokers Flattop Grill owner! These simple tips will ensure a lifetime of grilling enjoyment.

ARRIVAL

- Remove the pins from the door, which are used only for shipping.
- For safer shipment, wheels and/or charcoal basket handle may be shipped disassembled
- Attach wheels – lift up one side of the grill and place wooden blocks underneath for easier mounting of wheels – repeat for other side
 - Attach swivel wheels on the side with the pull handle
 - Attach fixed wheels on the side with the charcoal basket handle
- Attach the handle for the adjustable charcoal basket on the right side of the grill. Left-side handles may be purchased (produced on demand) if required.
- Attach the stainless steel front shelf to the front of the grill.

SEASONING YOUR NEW BBQ

- Wash cooking grates and griddles with warm water & soap.
- Apply a thin layer of cooking oil to the cooking grates, optional griddle, and interior surface.
- Spray the external surface with the included ACF-50, then wipe with a dry, clean microfiber cloth.
- Run the smoker with a bed of hot coals for at least 1 hour

OCCASIONAL MAINTENANCE

- Re-apply ACF-50 every 4 months to the external surface for protection against moisture, dirt, and corrosion.
- Do not cover when wet
- Yoder Smokers are manufactured with thick steel and painted with high heat stove paint. It is normal for moisture, salt, grease, etc. to cause some of the paint to wear off, or some small surface rust spots to occur. The thick steel ensures that your grill will never rust through, and the type of paint allows for quick and simple touch-ups that enable your grill to look great for many years.
- To touch up a spot, use a medium grit sandpaper to remove any rust. Clean and dry the area. Then apply 2-3 thin layers of the included high heat stove paint. Do not paint the interior surface.

YODER SMOKERS USA
customerservice@yodersmokers.com

YODER SMOKERS EUROPE
info@bbqeuropa.com

YODER SMOKERS
EUROPE